



INSTALLATION GUIDE



1. Drill a 4" hole into the wood floor.



2. Measure and cut a ABS or PVC piece as needed to ensure a secure connection with the P-trap below. Note that the drain body has an outlet of 2" (a coupling reducer of 1 1/2" is included).



3. Connect the drain to the P-trap. Glue coupling reducer (if necessary) to the drain body first, then to the P-trap. Apply glue to both ends for a safe installation.



4. Secure the drain body to the wood floor using screws or cement.



5. Do not obstruct the hole of the drain body. Be sure to leave enough space around the drain body.



6. Remove drain cap test



7. Install the piece to the tub's waste and overflow. Ensure the measurement between the base of the drain and P-trap will fit the tail piece.



8. For easier insertion, apply lubricant to the tailpiece. Be sure to position the bathtub and tail piece in line with the drain body.



9. Carefully insert the bathtub tailpiece into the drain body until the bathtub is in place.